

## Hold Button Adapter Master Compatibility List

AT&T/Lucent 21070	AT&T/Lucent 90529	GE 2-9488
AT&T/Lucent 262	AT&T/Lucent 90889	GE 2-9638-A
AT&T/Lucent 272	AT&T/Lucent 2462	GE 2-9975
AT&T/Lucent 412	AT&T/Lucent E2562	GE 25403
AT&T/Lucent 422	AT&T/Lucent E2662	GE 25404
AT&T/Lucent 4952	AT&T/Lucent EP5962	GTE 2350
AT&T/Lucent 612	AT&T/Lucent SIGNATURE	IBM 412
AT&T/Lucent 622	AT&T/Lucent TL76108	IBM 412CID
AT&T/Lucent 712	Bell 223	IBM 4900
AT&T/Lucent 722	Bell 232	Intellitouch ITC-420
AT&T/Lucent 732	Bell 259	Intellitouch 420I
AT&T/Lucent 742	Bell 261	Northern Telecom Unity
AT&T/Lucent 752	Bell 268	Pac Bell 261
AT&T/Lucent 8102	Bell 367	Pac Bell FE5350
AT&T/Lucent 812	Bell 470	Panasonic KX-T3110
AT&T/Lucent 822	Bell 52905	Panasonic KX-T3120
AT&T/Lucent 830	Bell Sonacor 412	Panasonic KX-T3122
AT&T/Lucent 832	Bell Sonacor 412CID	Panasonic KX-T3135
AT&T/Lucent 842	Bell Sonacor 4900	Panasonic KX-T3145
AT&T/Lucent 843	Bell Sonacor BE5200	Panasonic KX-T3155
AT&T/Lucent 853	Bell Sonacor BE5300	Panasonic KX-T3160
AT&T/Lucent 854	Bell Techline 420	Panasonic KX-T3165
AT&T/Lucent 874	Casio SI460	Panasonic KX-T3170
AT&T/Lucent 902	Casio SA400	Panasonic KX-T3175
AT&T/Lucent 912	Cortelco 4125	Panasonic KX-T3280
AT&T/Lucent 922	Cortelco 412541TP127S	Panasonic KX-T3281
AT&T/Lucent 944	Cortelco TP127S	Panasonic KX-T3980-H
AT&T/Lucent 945	Conair PR3001S	Panasonic KX-T3980-R7
AT&T/Lucent 952	Conair XS1200	Panasonic KX-T3981
AT&T/Lucent 953	Epic ET4000	Panasonic KX-TC930
AT&T/Lucent 954	Execufone ITC-420	Panasonic KX-TG2000
AT&T/Lucent 955	Execufone 420I	Panasonic KX-TG2720
AT&T/Lucent 964	GE 187	Panasonic KX-TG2730
AT&T/Lucent 974	GE 2-9418	Panasonic KX-TG2740
AT&T/Lucent 972	GE 2-9420-A	Panasonic KX-TG4000
AT&T/Lucent 982	GE 2-9435-A	Panasonic KX-TG4500
AT&T/Lucent 983	GE 2-9435-B	Panasonic KX-TG5480
AT&T/Lucent 984	GE 2-9435-C	Panasonic KX-TG6500
AT&T/Lucent 992	GE 2-9436-A	Panasonic KX-TG6502
AT&T/Lucent 993	GE 2-9438-A	Panasonic KX-TG6700
AT&T/Lucent 1040	GE 2-9450	Panasonic KX-TG6702
AT&T/Lucent 1070	GE 2-9451	Panasonic KX-TG650
AT&T/Lucent 1080	GE 2-9480	Panasonic KX-TG9391T
AT&T/Lucent 90240	GE 2-9481	Panasonic KX-TG9392T
	GE 2-9487	Panasonic KX-TGA200

Panasonic KX-TGA400	Radio Shack 612 / 43-461	Skutch HT-878
Panasonic KX-TGA420	Radio Shack ET-1753/43-1753	Smarttalk 208VX
Panasonic KX-TGA650	Radio Shack 43-430	South Western Bell FT325
Panasonic KX-TGA670	Radio Shack ET-146 / 43-642	South Western Bell FT360
Panasonic KX-TS20	Radio Shack ET-180	South Western Bell FT365BL
Panasonic KX-TS21	Radio Shack ET-181 / 43-470	South Western Bell FT412
Panasonic KX-TS25	Radio Shack ET-184	Spectra Phone FP-40M
Panasonic KX-TS27	Radio Shack ET-192	Sprint/Radio Shack SP-702/43-5702
Panasonic KX-TS208	Radio Shack ET-193	Sprint SP-705
Panasonic KX-TS3282	Radio Shack ET-293 / 43-622	Starplus II HAC2605
Panasonic KX-TS4100 C	Radio Shack ET-469 / 43-469	Starplus II HAC2606
Panasonic KX-TS4200 C	RCA 25403	TDS TDS-412
Panasonic KX-TS4300	RCA 25404	TMC ET4000
Panasonic VA-8400	RCA 25413	TT Systems 412
Panasonic PQLV30024ZB	RCA 25414	TT Systems 412CID
Phone Mate PMG-4125	RCA 25415	TT Systems 4300
Qwest NSQ412	RCA 25423	TT Systems 4900
Radio Shack 1752	RCA 25424	TT Systems 5200
Radio Shack 1753	RCA 25425	TT Systems 5300
Radio Shack 206 – old	RCA 25450	TT Systems 7993
Radio Shack 208 – old	SBC 2105	Uniden UB-420
Radio Shack 209 – old	SBC 4000	Uniden 420
Radio Shack 210 / 43-623	SBC 410	Verizon NSQ412
Radio Shack 212 / 43-463	SBC 420	