

**Hold Button Adapter Master Compatibility List**

AT&T/Lucent 21070	AT&T/Lucent EP5962
AT&T/Lucent 262	AT&T/Lucent SB67118
AT&T/Lucent 272	AT&T/Lucent SIGNATURE
AT&T/Lucent 412	AT&T/Lucent TL76108
AT&T/Lucent 422	Bell 223
AT&T/Lucent 4952	Bell 232
AT&T/Lucent 612	Bell 259
AT&T/Lucent 622	Bell 261
AT&T/Lucent 712	Bell 268
AT&T/Lucent 722	Bell 367
AT&T/Lucent 732	Bell 470
AT&T/Lucent 742	Bell 52905
AT&T/Lucent 752	Bell Sonecor 412
AT&T/Lucent 8102	Bell Sonecor 412CID
AT&T/Lucent 812	Bell Sonecor 4900
AT&T/Lucent 822	Bell Sonecor BE5200
AT&T/Lucent 830	Bell Sonecor BE5300
AT&T/Lucent 832	Bell Techline 420
AT&T/Lucent 842	Casio SI460
AT&T/Lucent 843	Casio SA400
AT&T/Lucent 853	Conair PR3001S
AT&T/Lucent 854	Conair XS1200
AT&T/Lucent 874	Cortelco 4125
AT&T/Lucent 902	Cortelco 412541TP127S
AT&T/Lucent 912	Cortelco TP127S
AT&T/Lucent 922	Cortelco 2740
AT&T/Lucent 944	Cortelco 2750
AT&T/Lucent 945	Epic ET4000
AT&T/Lucent 952	Execufone ITC-420
AT&T/Lucent 953	Execufone 420I
AT&T/Lucent 954	GE 187
AT&T/Lucent 955	GE 2-9418
AT&T/Lucent 964	GE 2-9420-A
AT&T/Lucent 974	GE 2-9435-A
AT&T/Lucent 982	GE 2-9435-B
AT&T/Lucent 983	GE 2-9435-C
AT&T/Lucent 984	GE 2-9436-A
AT&T/Lucent 992	GE 2-9438-A
AT&T/Lucent 993	GE 2-9480
AT&T/Lucent 1040	GE 2-9481
AT&T/Lucent 1070	GE 2-9487
AT&T/Lucent 1080	GE 2-9488
AT&T/Lucent 90240	GE 2-9490
AT&T/Lucent 90529	GE 2-9638
AT&T/Lucent 90889	GE 2-9975
AT&T/Lucent E2562	GE 25403
AT&T/Lucent E2662	GE 25404

**Hold Button Adapter Master Compatibility List**

GTE 2350	Panasonic KX-TS25
IBM 412	Panasonic KX-TS27
IBM 412CID	Panasonic KX-TS208
IBM 4900	Panasonic KX-TS3282
Intellitouch ITC-420	Panasonic KX-TS4100
Intellitouch 420I	Panasonic KX-TS4200
Northern Telecom Unity	Panasonic KX-TS4300
Pac Bell 261	Panasonic KX-TSC14
Pac Bell FE5350	Panasonic VA-8400
Panasonic KX-T3110	Panasonic PQLV30024ZB
Panasonic KX-T3120	Phone Mate PMG-4125
Panasonic KX-T3122	Qwest NSQ412
Panasonic KX-T3135	Radio Shack 1752
Panasonic KX-T3145	Radio Shack 206
Panasonic KX-T3155	Radio Shack 208
Panasonic KX-T3160	Radio Shack 209
Panasonic KX-T3165	Radio Shack 210 / 43-623
Panasonic KX-T3170	Radio Shack 212 / 43-463
Panasonic KX-T3175	Radio Shack 612 / 43-461
Panasonic KX-T3280	Radio Shack 43-373D
Panasonic KX-T3281	Radio Shack ET-1753/43-1753
Panasonic KX-T3980-H	Radio Shack 43-430
Panasonic KX-T3980-R7	Radio Shack ET-146 / 43-642
Panasonic KX-T3981	Radio Shack ET-180
Panasonic KX-TC930	Radio Shack ET-181 / 43-470
Panasonic KX-TG2000	Radio Shack ET-184
Panasonic KX-TG2720	Radio Shack ET-192
Panasonic KX-TG2740	Radio Shack ET-193
Panasonic KX-TG4000	Radio Shack ET-293 / 43-622
Panasonic KX-TG4500	Radio Shack ET-469 / 43-469
Panasonic KX-TG5480	RCA 25201
Panasonic KX-TG6500	RCA 25210
Panasonic KX-TG6502	RCA 25250
Panasonic KX-TG6700	RCA 25255
Panasonic KX-TG6702	RCA 25403
Panasonic KX-TG650	RCA 25404
Panasonic KX-TG9381T	RCA 25413
Panasonic KX-TG9382T	RCA 25414
Panasonic KX-TG9391T	RCA 25415
Panasonic KX-TG9392T	RCA 25423
Panasonic KX-TGA200	RCA 25424
Panasonic KX-TGA400	RCA 25425
Panasonic KX-TGA420	SBC 2105
Panasonic KX-TGA650	SBC 4000
Panasonic KX-TGA670	SBC 410
Panasonic KX-TS20	SBC 420
Panasonic KX-TS21	Skutch HT-878

**Hold Button Adapter Master Compatibility List**

Smarttalk 208VX  
Sony IT-M804  
South Western Bell FT325  
South Western Bell FT412  
Spectra Phone FP-40M  
Sprint/Radio Shack SP-702/43-5702  
Sprint SP-705  
Starplus II HAC2605  
Starplus II HAC2606  
TDS TDS-412  
TMC ET4000  
TT Systems 412  
TT Systems 412CID  
TT Systems 4300  
TT Systems 4900  
TT Systems 5200  
TT Systems 5300  
TT Systems 7993  
Uniden UB-420  
Uniden 420  
Verizon NSQ412